
Notes

1. Please place the device on the flat position, do not tilt it.
2. Do not mix water into the essential oil.
3. Please operate and maintain the device refer to the instruction. Do not dismantle or modify the device.
4. Please use alcoholic solution to wash the bottle and atomize core when the device has not been used for a long time.
5. Please wash atomize core with alcoholic solution when the device operate for 2 months.



Troubleshooting

Problem	Solution
Non atomization	1. Check if the power is on. 2. Check if the time period is set during the non-working period. 3. Check if the air pump is working. 4. Check if the air intake seal is leaking or if the seal is broken. 5. The suction pipe is blocked or detached.
Small atomization	1. Check for broken inlet seals and clogged suction hose. 2. Check the atomisation system and essential oil bottle seals for damage or dislodgement.
Oil leakage	1. Check whether the atomization system is damaged. 2. Check whether the sealing rings of atomization system and essential oil bottles are damaged or fall off. 3. Check whether the essential oil bottle is tightened.
Abnormal noise	1. Check air pump for looseness and refasten air pump. 2. Check the air pump for damage and replace it with a new one.

Equipment Maintenance

In order to ensure the best aroma effect, please check and maintain the equipment regularly, as follows:

1. Open the device remove the used essential oil bottle.
2. Pour proper amount of alcohol into the essential oil bottle and clean it.
3. After cleaning, pour in a small amount of alcohol, install the essential oil bottle on the equipment, turn on the equipment and work for 5 to 10 minutes.
4. Turn off the power after cleaning the equipment.
5. Take out the essential oil bottle, put in the essential oil, install it on the equipment.

After Sales Service


The equipment is sold within one year from the date of sale. Providing paid maintenance beyond the warranty period. The following man-made or accidental damage is not covered by the warranty:

1. Use a power adapter that is not equipped with this device or an insecure power supply socket to cause the device to be short-circuited.
2. Do not attempt to disassemble the device, otherwise it is deemed to automatically give up the warranty.
3. It is not used in accordance with the specifications correctly, the equipment is damaged by the leakage of essential oil after the water is injected and the essential oil is inverted.
4. If you encounter any after-sales problems, you can contact the authorized sales service providers in each region or contact our sales center.

HOUSE OF DUAA
Scents of the Holy & Heritage

Véra Glow
PRODUCT INSTRUCTION

Installation Instructions



- Use a power adapter compatible with the outlet.
- Avoid wet plugs; dry thoroughly before use.
- Replace damaged plugs (e.g., cracked insulation, bent prongs).
- Keep away from children/pets to prevent hazards.

Parameters

Coverage Area : Up to 1000 Square Feet.
Power Consumption: 5W
Input Voltage: AC 100V-240V
Noise Level: <36 dB (Ultra Quiet)
Tank Capacity: 100 ml
Setup: Plug & Play - no cables required

Gear Description

Level	L	M	H	G+
Work(s)	5	10	15	20
Stop(s)	300	270	180	90
Oil consumption(g/h)	0.009	0.025	0.042	0.105

Accessories



Adapter×1 Cotton Pad×1 Instructions×1

App Operation And Settings

I. Download and install the APP

Please enter the Apple Store, Google App Market, Android App Market and enter **HOUSE OF DUAA** to download the control APP.


Download on the App Store

Download for Google Play


II. Connection operation

1. Before operation, please turn on the mobile phone Bluetooth.
2. After opening the APP, register an account and log in, please agree to the location and network permissions of the APP, otherwise the fragrance device may not be successfully bound


1. Click to add device



2. Select the device to connect




3. Binding successful




4. Press the"On" to switch the device on.




5. Tap "Lighting" to set the mood lighting




6. Tap 'Timer' to set the timer




7. Set gear, time period



8. Click on '⚙' to view device details



Function Description



Mode Description

Mode	Instructions
APP	1. Control device on/off, view parameters, and set timing (up to 7 segments) via APP. 2. Control ambient light: switch on/off, adjust color, and brightness. 3. In APP mode, use device buttons to switch gears or modes.
Light Sensing	1. In bright environments, the device operates and the ambient light turns off. 2. In dim environments, the device stops and the ambient light turns on. 3. Only manual grear adjustment is supported in this mode.
Dark Sensing	1. In low light, the device and ambient light are on. 2. In bright light, the device and ambient light are off. 3. Only manual grear adjustment is supported in this mode.
Human Body Sensing	1. When motion (of people/objects) is detected, both the device and ambient light activate and remain on. 2. If no motion is detected within 10 minutes, the device stop working after 10 minutes, while the ambient light turns off within 1 minute.

Notice: Do not block the sensing area. If detection fails, check for obstructions around the device and ensure the sensing area is clean.

Description of Ambient Light

Operating	1. APP mode: Control ambient light's color & brightness via APP. 2. Light/dark sensing mode: On when dim, off when bright. 3. Human body sensing mode: On with movement, off in 1 min if no movement.
Control	When the device starts, the light is on by default; double-click the Gear Button to toggle it.

Instructions:
1. APP control is only effective in APP mode.
2. Light/dark sensing mode: Off in bright light (manual activation lights up for 1s to indicate "light on"); auto - lights up in dim light.

Anti-tip Protection

This device features an intelligent anti-tilt protection system: the water pump stops automatically if the tilt angle exceeds 45° or it is fully inverted (other functions continue operating) to ensure safety.

- **Tilt State:** The air pump stops, and the buzzer emits a rapid "beep beep" alarm.
- **Recovery State:** When righted to upright, pump restarts automatically; it signals with a single beep.

Notes:
- The air pump's start-stop process is automatic; no manual intervention is required.
- Always place the device on a stable, level surface during use to prevent accidental activation of the protective mechanism.
- This function only stops the air pump operation; the device power remains on. For a complete shutdown, press the power key.