



Notes

1. Please place the device on the flat position, do not tilt it.
2. Do not mix water into the essential oil.
3. Please operate and maintain the device refer to the instruction. Do not dismantle or modify the device.
4. Please use alcoholic solution to wash the bottle and atomize core when the device has not been used for a long time.
5. Please wash atomize core with alcoholic solution when the device operate for 2 months.



Troubleshooting

Problem	Solution
Non atomization	1. Check if the power is on. 2. Check if the time period is set during the non-working period. 3. Check if the air pump is working. 4. Check if the air intake seal is leaking or if the seal is broken. 5. The suction pipe is blocked or detached.
Small atomization	1. Check for broken inlet seals and clogged suction hose. 2. Check the atomisation system and essential oil bottle seals for damage or dislodgement.
Oil leakage	1. Check whether the atomization system is damaged. 2. Check whether the sealing rings of atomization system and essential oil bottles are damaged or fall off. 3. Check whether the essential oil bottle is tightened.
Abnormal noise	1. Check air pump for looseness and refasten air pump. 2. Check the air pump for damage and replace it with a new one.

Equipment Maintenance

In order to ensure the best aroma effect, please check and maintain the equipment regularly, as follows:

1. Open the device remove the used essential oil bottle.
2. Pour proper amount of alcohol into the essential oil bottle and clean it.
3. After cleaning, pour in a small amount of alcohol, install the essential oil bottle on the equipment, turn on the equipment and work for 5 to 10 minutes.
4. Turn off the power after cleaning the equipment.
5. Take out the essential oil bottle, put in the essential oil, install it on the equipment.

After Sales Service


The equipment is sold within one year from the date of sale. Providing paid maintenance beyond the warranty period. The following man-made or accidental damage is not covered by the warranty:

1. Use a power adapter that is not equipped with this device or an insecure power supply socket to cause the device to be short-circuited.
2. Do not attempt to disassemble the device, otherwise it is deemed to automatically give up the warranty.
3. It is not used in accordance with the specifications correctly, the equipment is damaged by the leakage of essential oil after the water is injected and the essential oil is inverted.
4. If you encounter any after-sales problems, you can contact the authorized sales service providers in each region or contact our sales center.




Véra Grand PRODUCT INSTRUCTION

Installation Instructions



1
Insert key, rotate 90°
counterclockwise to
unlock.



2
Turn counterclockwise to
unscrew the essential oil
bottle.




3
Add essential oil to the
bottle and replace.

Parameters


Capacity	: 150mL
Power	: 6.5W
Voltage	: DC12V
Weight	: 2.1KG
Coverage	: 600m ³
Noise	: < 36dB
Size	: 188*80*240mm

Wall Mount Instructions



1. Drill positioning holes in the wall at appropriate locations and fix the hanging board with screws.
2. After inserting it into the notch on the back of the chassis, lock the screw at the bottom.

Accessories



App Operation And Settings

I. Download and install the APP

Please enter the Apple Store, Google App Market, Android App Market and enter **HOUSE OF DUAA** to download the control APP.



II. Connection operation

- Before operation, please turn on the mobile phone BT.
- After opening the APP, register an account and log in, please **agree the location and network permissions of the APP**, otherwise the fragrance device may not be successfully bound.
- Before binding the device, press and hold the reset button for 5 seconds, and then proceed to the next step after the reset is complete.

1. Click to add device

2. Select the device to connect

3. Enter WiFi password

4. Waiting for network progress

3. Binding successful

4. Press the "On" to switch the device on.

5. Tap 'Timer' to set the timer

6. Set gear, time period

Function Description

Key Description

1. A key: set concentration and working time, click to switch different pages.
2. On key: short press to start; press and hold for 3 seconds to turn off the machine when it is unlocked.
3. + key and - key: adjust time, concentration gear and week selection.
4. Setting key:
 - ① confirm that the selected page enters the setting state;
 - ② long press the set key to adjust the device time.

Operating Instructions

1. **Unlock / lock:** Press " " and " " at the same time to lock or unlock the screen. The default state is unlock when power on.
2. **Factory reset:** Keep pressing " " until the screen turn white and flashing, then power off/on the machine.
3. **Testing mode:** Unlock the machine and keep pressing " " and there will be 10 seconds testing mode. Stop testing if stop pressing " ".
4. **Time Setting:** Unlock the machine, and keep pressing " " until there is number flashing on the screen. Press " " and " " to set the time: Hours, Minutes, Week days. And then press " " for confirmation.
5. **Enter the setting:** Unlock the machine and press " ".

HVAC Connection

1. Install the machine in a suitable location and replace the nozzle with the Quick Connector.

2. Insert the spray tube into the Quick Connector and guide it to the installation point.

PE Trachea

Note:

1. Ensure the pipeline is laid smoothly and avoid sharp bends.
2. Ensure the machine is positioned below the air outlet to prevent fragrance spray from flowing back.

Gear Description																				
Gear Position	G1	G2	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12	G13	G14	G15	G16	G17	G18	G19	G20
Working Time(s)	5	5	5	5	5	10	10	10	10	10	15	15	15	15	15	20	20	20	20	20
Stop Time(s)	660	630	600	570	540	510	480	450	420	390	360	330	300	270	240	210	180	150	120	90