




Notes

1. Please place the device on the flat position, do not tilt it.
2. Do not mix water into the essential oil.
3. Please operate and maintain the device refer to the instruction. Do not dismantle or modify the device.
4. Please use alcoholic solution to wash the bottle and atomize core when the device has not been used for a long time.
5. Please wash atomize core with alcoholic solution when the device operate for 2 months.



Troubleshooting

Problem	Solution
Non atomization	1. Check if the power is on. 2. Check if the time period is set during the non-working period. 3. Check if the air pump is working. 4. Check if the air intake seal is leaking or if the seal is broken. 5. The suction pipe is blocked or detached.
Small atomization	1. Check for broken inlet seals and clogged suction hose. 2. Check the atomisation system and essential oil bottle seals for damage or dislodgement.
Oil leakage	1. Check whether the atomization system is damaged. 2. Check whether the sealing rings of atomization system and essential oil bottles are damaged or fall off. 3. Check whether the essential oil bottle is tightened.
Abnormal noise	1. Check air pump for looseness and refasten air pump. 2. Check the air pump for damage and replace it with a new one.

Equipment Maintenance

In order to ensure the best aroma effect, please check and maintain the equipment regularly, as follows:

1. Open the device remove the used essential oil bottle.
2. Pour proper amount of alcohol into the essential oil bottle and clean it.
3. After cleaning, pour in a small amount of alcohol, install the essential oil bottle on the equipment, turn on the equipment and work for 5 to 10 minutes.
4. Turn off the power after cleaning the equipment.
5. Take out the essential oil bottle, put in the essential oil, install it on the equipment.

After Sales Service

The equipment is sold within one year from the date of sale. Providing paid maintenance beyond the warranty period. The following man-made or accidental damage is not covered by the warranty:


1. Use a power adapter that is not equipped with this device or an insecure power supply socket to cause the device to be short-circuited.
2. Do not attempt to disassemble the device, otherwise it is deemed to automatically give up the warranty.
3. It is not used in accordance with the specifications correctly, the equipment is damaged by the leakage of essential oil after the water is injected and the essential oil is inverted.
4. If you encounter any after-sales problems, you can contact the authorized sales service providers in each region or contact our sales center.




Véra

PRODUCT INSTRUCTION

Installation Instructions



1
Rotate 15° in the direction shown towards "lock".




2
Open the front cover to take out the oil bottle.



3
Open the bottle counterclockwise, add the essential oil.



4
Plug into the socket and start working.



- Use a power adapter compatible with the outlet.
- Avoid wet plugs; dry thoroughly before use.
- Replace damaged plugs (e.g., cracked insulation, bent prongs).
- Keep away from children/pets to prevent hazards.

Parameters

Capacity	: 130mL
Power	: 2W
Voltage	: AC100V-240V
Weight	: 0.3KG
Coverage	: 300m³
Noise	: < 36dB
Material	: Plastic
Size	: 74*73*217mm
Color	: Black, White

Accessories



Adapter×1



Cotton Pad×1



Instructions×1

App Operation And Settings

I. Download and install the APP


Please enter the Apple Store, Google App Market, Android App Market and enter **HOUSE OF DUAA** to download the control APP.




II. Connection operation

- **Before operation, please turn on the mobile phone BT.**
- After opening the APP, register an account and log in, please **agree the location and network permissions of the APP**, otherwise the fragrance device may not be successfully bound.
- Before binding the device, press and hold the reset button for 5 seconds, and then proceed to the next step after the reset is complete.


1. Click to add device



2. Select the device to connect




3. Binding successful




4. Press the "On" to switch the device on.




5. Tap 'Timer' to set the timer



6. Set gear, time period



Function Description



Reset Key Description	
Single-click	Power switch
Long press	Long press for 5 seconds to reset device connection and restore factory settings.
Double-click	It will switch modes, switching the body sensor mode to ring 4 times and switching the APP mode to ring twice.

Note:
The indicator light is always on when the device is powered on, and the buzzer will sound for about 4 seconds when it is reset.

Mode description	
APP mode	1.The indicator light of the device is always on, and the device is running according to the set timing section. 2.The buzzer sounds twice when switching back to APP mode.
Body sensor mode	1. The indicator light will go out if the human body sensor mode is not connected or not connected correctly. 2. When the sensor detects the human body, the device starts to work for ten minutes, during this period, if the human body is detected again, it will work for another ten minutes, and so on. 3. When the sensor fails to detect the human body, the indicator light will turn off, if the human body is not detected after ten minutes, the device will stop working and enter standby until the human body is detected again. 4. From APP mode switch back to the body sensor mode buzzer sounded four times.

Gear Description																				
Gear Position	G1	G2	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12	G13	G14	G15	G16	G17	G18	G19	G20
Working Time(s)	5	5	5	5	5	10	10	10	10	10	15	15	15	15	15	20	20	20	20	20
Stop Time(s)	660	630	600	570	540	510	480	450	420	390	360	330	300	270	240	210	180	150	120	90